

FREEDOM CORE II FlexSensor™

Freedom Core II FlexSensor™ is the most innovative security and merchandising solution in the marketplace. The patent pending FlexSensor™ architecture allows you to power, alarm and track on the most popular wearable devices. Other versions of the FlexSensor™ provide alarming-only security for multiple retail product categories.



FREEDOM CORE II FlexSensor™

SAFEGUARDS WEARABLES AND OTHER RETAIL PRODUCTS
NEEDING MERCHANDISING SECURITY

MULTIPLE SECURITY SENSORS FOR COMPLETE MERCHANDISING FLEXIBILITY

4-Port Alarm Module:

- Integrated Module for all FlexSensors™
- 'Quick Release' feature for fast and easy re-merchandising
- Multiple alarm points (cut, disconnected or removal)
- Powers and alarms all wearable devices
- Same MTI Intellikey™ as Freedom Micro

FlexCircuit™ Sensor Cable:

- Available in white or black, straight or coiled
- Alarms if disconnected from alarm module
- Easy to attach FlexSensors™

Wearables FlexSensor™:

- Tear resistant
- Powers and alarms
 - Alarm-only sensor also available
- Multiple alarm points (cut, torn or disconnected)
- Allows consumers to try on products
- Available in black

Loop FlexSensor™:

- Tear resistant
- Alarming only
- Multiple alarm points (cut, torn or disconnected)
- Ideal for multiple retail categories needing security
- Available in black



4-port Alarm Module



Coiled FlexCircuit™ Sensor Cable with Wearables FlexSensor™



Straight FlexCircuit™ Sensor Cable with Wearables FlexSensor™



Wearables FlexSensor™ (Green shown for detail only)

FREEDOM CORE II FlexSensor™

TO ORDER:

Wearables FlexSensors Power	Part Number
SONY SMARTBAND, WEARABLES (AVAILABLE JULY)	153-0881-00
SONY SMARTWATCH 3, WEARABLES (AVAILABLE JULY)	153-0882-00
SAMSUNG GEAR FIT, WEARABLES	153-0884-00
SAMSUNG GEAR 2/ NEO, WEARABLES	153-0886-00
LG G WATCH R/ LG URBANE, WEARABLES	153-0887-00
LG LIFEBAND TOUCH, WEARABLES	153-0888-00
MICROSOFT BAND, WEARABLES	153-0889-00
PEBBLE, WEARABLES	153-0892-00
LG G WATCH R, WEARABLES	153-0893-00
SAMSUNG GEAR S, WEARABLES	153-0894-00
FITBIT SURGE, WEARABLES	153-0891-00

Watch Stands	Part Number
ACRYLIC DISPLAY CLEAR	160-0203-0000
ACRYLIC DISPLAY BLACK	160-0203-0001
ACRYLIC DISPLAY WHITE	160-0203-0011

Wearables FlexSensors Alarming-Only	Part Number
ALARMING ONLY, WEARABLES	153-0879-00

FlexCircuit Sensors	Part Number
DISC SENSOR STRAIGHT BLACK	421-2145-0001
DISC SENSOR STRAIGHT WHITE	421-2145-0011
DISC SENSOR COILED BLACK	421-2146-0001
DISC SENSOR COILED WHITE	421-2146-0011

Loop FlexSensor (Retail Merchandise Sensor)	Part Number
LOOP FLEXSENSOR	153-0880-00